Client

1.Client reads 2-4 command line arguments

<u>Mandatory</u>


- -IP address of server
- -Port of server

Optional

- -Integer used to communicate if the lightbulb should turn on or off(1 for on, 2 for off)
- -String used to communicate the color change of the lightbulb
- -If the optional integer and string arguments are provided the lightbulb should switch on and change color
- -If only the optional integer argument is provided the lightbulb should only turn off or remain off
- -If only the optional string argument is provided the lightbulb should only change its color.
- 2.Send a request with the command line arguments of the ip address and port of the server using the message format shown below
- 3. Wait for a response using a 1 second timeout period.
 - -If a response arrives with the timeout period, print out the server response as shown below
 - -If no response retry for a maximum of three times before printing an error message and exiting

Server

- 1. Server reads 2 command line arguments
 - -IP address of server
 - -Port of server
- 2. Server responds to request from client
 - -Turns on the lightbulb(if applicable)
 - -Changes the light color(if applicable)
 - -Turns off the lightbulb(if applicable)
 - -Returns the status of the lightbulb
- 3. Returns an error code based on these conditions
 - -Lightbulb won't turn on(1)
 - -Color not supported(2)
 - -Message format not supported(for example the power state of the lightbulb uses 0, 1, and 2 but a 3 was given)



Message Type(16 bits): 1 on request, 2 on response

Return Code(16 bits): 0 on request. For response 0 if no errors, 1 if bulb wont turn on, 2 if color is not supported, 3 if the message format is incorrect

Message Identifier(32 bits): Unique identifier that is sent to server and server echos same number back. Random generated number in range between 1-100

Request Power State(16 bits):0 for default(no change), else integer given in command line argument

Answer Power State(16 bits):0 in request because power state is unknown, for response 1 if lightbulb is on, 2 if lightbulb is off

Request Color Length(16 bits):In request length is used to carry string for the type of color,length is 0 if color change is not specified.

Answer Color Length(16 bits):In request length is 0 because no answer, on response length is used to carry the string of the bulb's active color.

Request Color String(variable length):In request, string is the color that the lightbulb should be changed to if specified.

Answer Color String(variable length):In request there is no answer color string, in response the server sends the color of the active lightbulb color setting.

Test Output

Test Case 1: Client Output (Turning on the lightbulb and changing the color)

Sending Request to 127.0.0.1, 9999:

Message ID: 23

Request Power State: 1

Request Color Length: 4 bytes

Request Color: blue

Received Response from 127.0.0.1, 9999:

Return Code 0 (No Errors)

Message ID: 23

Request Power State: 1

Request Color Length: 4 bytes

Request Color: blue Answer Power State : 1 Answer Color Length: 4 bytes

Answer Color: blue

Test Case 2: Client Output (Changing color of lightbulb)

Sending Request to 127.0.0.1, 9999:

Message ID: 24

Request Power State: 0

Request Color Length: 4 bytes

Request Color: blue

Received Response from 127.0.0.1, 9999:

Return Code 0 (No Errors)

Message ID: 24

Request Power State: 0

Request Color Length: 4 bytes

Request Color: blue Answer Power State : 1

Answer Color Length: 4 bytes

Answer Color: blue

Test Case 3: Client Output(Determine the status of the light)

Sending Request to 127.0.0.1, 9999:

Message ID: 25

Request Power State: 0

Request Color Length: 0 bytes

Request Color:

Received Response from 127.0.0.1, 9999:

Return Code 0 (No Errors)

Message ID: 25

Request Power State: 0

Request Color Length: 0 bytes

Request Color:

Answer Power State: 1

Answer Color Length: 4 bytes

Answer Color: blue

Test Case 4: Client Output(Turn the light off)

Sending Request to 127.0.0.1, 9999:

Message ID: 26

Request Power State: 2

Request Color Length: 0 bytes

Request Color:

Received Response from 127.0.0.1, 9999:

Return Code 0 (No Errors)

Message ID: 26

Request Power State: 2

Request Color Length: 0 bytes

Request Color:

Answer Power State: 2

Answer Color Length: 4 bytes

Answer Color: blue

Test Case 5: Client Output(bulb is not functioning)

Sending Request to 127.0.0.1, 9999:

Message ID: 26

Request Power State: 1

Request Color Length: 4 bytes

Request Color: blue

Received Response from 127.0.0.1, 9999:

Return Code 1 (bulb is not functioning)

Message ID: 26

Request Power State: 1

Request Color Length: 4 bytes

Request Color: blue

Test Case 6: Client Output(Color not supported)

Sending Request to 127.0.0.1, 9999:

Message ID: 27

Request Power State: 0

Request Color Length: 4 bytes

Request Color: buel

Received Response from 127.0.0.1, 9999:

Return Code 2 (color not supported)

Message ID: 27

Request Power State: 0

Request Color Length: 4 bytes

Request Color: buel

Test Case 7: Client Output(message format not supported)

Sending Request to 127.0.0.1, 9999:

Message ID: 28

Request Power State: 636475 Request Color Length: 4 bytes

Request Color: blue

Received Response from 127.0.0.1, 9999:

Return Code 3 (message format not supported)

Message ID: 28

Request Power State: 636475 Request Color Length: 4 bytes

Request Color: blue

Test Case 8: Client Output(no response)

Sending Request to 127.0.0.1, 9999:

Message ID: 88

Request Power State: 0

Request Color Length: 4 bytes

Request Color: blue Request timed out ...

Sending Request to 127.0.0.1, 9999:

Request timed out ...

Sending Request to 127.0.0.1, 9999: Request timed out ... Exiting Program.